

Advanced settings diagram

Sequencer mode

Grids can also work as a plain euclidean sequencer.

- ○ ○ Grids is yet another euclidean sequencer
- ● ● Grids is back to drumming duties

When euclidean sequencer mode is enabled, the MAP X / Y / CHAOS knobs have alternate functions, (STEPS 1-3) as shown in red on the panel – they control the duration (number of steps) of the sequence; while the FILL knobs control the fill rate.

Trig / Gate output

- ○ ○ Outputs are 1 ms triggers
- ● ● Outputs are gates

Clock resolution

- ○ ○ 4ppqn
- ● ○ 8ppqn
- ○ ● 24ppqn

Tap button function

- ○ ○ Tap to restart at the beginning of the sequence
- ● ● Tap to set the tempo

Outputs configuration

Grids can output either: three individual accent tracks (one per instrument); or a **global accent track**, a **clock** signal (received on the clock input or internal, whichever is used), and a **reset trigger** sent at the beginning of the pattern.

- ○ ○ ACC 1 / ACC 2 / ACC 3
- ● ● ACC / CLK / RST

